

ASAP Pole Guy Wire Mounts



This guy wire mount design works perfectly with the ASAP Pole and could easily be adapted for other Mega Trees. It does not interfere with operation of the push pole or winch and allows for guy wires to be attached directly to the main pole.

Use at your own discretion. Depending on the design and height of your Mega Tree, one set of guy wires may be insufficient. I use this on a 15' Mega Tree with the guy wires attached just below the top of the first 10' section of conduit and the Mega Tree has withstood frequent 60-70 MPH winds without issue.

Parts List:

2 - 3/8" x 6" Eye Bolts with Nut

1 - 5/16" x 3 1/4" Eye Bolt with Nut

2 - 5/16" Washers

1 - 5/16" Nut

2 - 1 1/2" Muffler Clamps with 3/8" U-Bolts and Washer Nuts *

* U-Bolts are not used



Assembly:



Drill a 5/16" into the center of one of the Muffler Clamps.

Grind down two opposite sides of the 5/16" Nut so that it will fit inside of the Muffler Clamp as shown.



Next further grind the 5/16" Nut to match the curvature of the Muffler Clamp. A Dremel tool with a rough grit sanding disk work well for this.



Cut 7/8" off the threads of the 5/16" Eye Bolt.



Assemble the 5/16" Eye Bolt into the Muffler Clamp as shown and tighten. I recommend using thread locker during assembly of all parts.



On the 3/8" Eye Bolts place the nut at the top of the threads, then insert the 5/16" washer and slide the other Muffler Clamp into position.



Assemble both Muffler Clamps and Eye Bolts together using the Washer Nuts onto the ASAP Pole and tighten.



